

# FRESH-AIRE MINIUV

## TECHNICAL BULLETIN

### For Installation in Gree, Daiken and Fujitsu Wall-Mounted Ductless Mini-Split Systems

On these three systems the drain pan cannot be removed and the lamps are installed behind the main supply vents. On some of these models the power supply may have to be installed on the outside, ideally on the top or on the side of the unit. The ideal location is in the back near the refrigerant lines. On some of these models, this space is very limited.

After locating your power supply location, mount the lamps. Remove the front white louvers, then the gray baffles. You will need to drill a hole to feed the lamp cords thru. Using a step bit, drill a hole on either or both sides of the gray shroud area. Mount your lamp clips with the lamps attached and in position near the blower. The access to the blower area changes on different brands and models. The lamps need to always be in between the blower and louvers as the growth generates on the blower more often than the coil. You can also refer to our installation video below.

<http://www.freshaireuv.com/mini-installation.html>



After baffle removal, position the lamps facing the blower wheel, then run lamp cords through drilled hole, per above.