



Meet the Nest Learning Thermostat.



Display
Turns blue when cooling and orange when heating.

Status
Shows Time-to-Temp and if it's heating, cooling or using Airwave.

Current temperature
Shows the temperature in your home.

Target temperature
Shows the temperature you want to reach.

Nest Leaf
Appears when you're saving energy.

Sensor window
Contains temperature, humidity, light and activity sensors.

Get to know each other.

Press the ring for the menu, then rotate to select.



 **Thermostat**
If you have heating and cooling, easily switch between them manually or automatically.

 **Energy History**
See how much energy you've used in the last ten days and why.

 **Schedule**
See or adjust the schedule the Nest Thermostat has learned from your temperature changes.

 **Away**
Set the Nest Thermostat to Away when you leave to save energy while you're gone.

 **Settings**
Choose options like Thermostat Lock and Fan Control.

Control from anywhere.

Connect your thermostat to Wi-Fi and you can control it from your phone, tablet or laptop. Just download the free Nest app or go to nest.com/account



We take your privacy seriously. Go to nest.com/privacy to find out more. Visit nest.com/support for more info about Nest's facts and figures.

Your life with Nest.

Install and setup

During setup, tell Nest what system you have, and System Match will turn on specific features to keep you comfortable and help you save. Go to nest.com/support if you need help.



Teach it well

The Nest Thermostat learns from you. Just change the temperature when you wake up, go to bed, leave the house and come home. After a few days, Nest will do it for you.

Day 1

Remote control

Download the free Nest app for your phone or tablet. Connect the Nest Thermostat to Wi-Fi. Then control your thermostat from anywhere.



Day 7



Auto-Schedule

By now, the Nest Thermostat has learned the temperatures you like and created a schedule. You can edit your schedule on the thermostat, the Nest app or the web.

Changing the temperature just one degree can lower your energy use up to 5%.



Nest Leaf


The Leaf appears when you choose a temperature that saves energy.



Auto-Away

It automatically adjusts to an energy-saving temperature when you're away.

Maximize savings with Auto-Away by setting your Away "heat to" temp below 65° and your Away "cool to" temp above 80°.



Energy History

See when you used heating and cooling and how your adjustments, the weather, and Auto-Away affected your energy use.

Day 30

Home Report

Your monthly Home Report email is packed with energy info and tips to help you save.

Day 90



Airwave

Lower your AC bill. Airwave cuts AC runtime automatically and still keeps you cool when home humidity isn't too high.



Heat • Cool

Set a temperature range and it automatically switches between heating and cooling to keep you comfortable.

Seasons change

When you switch from heat to cool or vice versa, the Nest Thermostat will learn a new schedule.

Going on vacation? Start saving money the minute you walk out the door by manually turning on Away.